CABINET PARTS

For Model: WED5310SQ0
(Designer White)

29"ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: WED5310SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8577188	Installation Instructions
	W10042960	Sheet, Cycle Feature
	8578370	Use & Care Guide
	8528192	Wiring Diagram

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

	677818	Dryer
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, Hex Washer Head
4	8541400	Bracket, Cabinet
5	3396795	Cover, Terminal Block
6	3403630	Plug, Strike Hole
7	3396805	Panel, Rear
10	3406109	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
12	3404413	Plug−Hole
15	3394083	Clip, Front Panel (2)
16	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2) (Not Included)
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)
18	8530603	Cabinet (Includes Illus. 4)
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21	3403444	Panel, Front
23	685203	Clip, Felt Pad (3)
24	3389441	Catch, Door Assembly
27	342055	Screw, 8−18 x 1/2
28	3405514	Hinge Door
33	3403431	Strike, Door
35	3402341	Door, Rear
36	3402335	Door, Front
37	8566059	Handle, Door
38	3406129	Seal & Bearing Assembly
39	279393	Terminal Block Kit (For Terminal Block)
40	3393008	Screw, 10−16 x 1/2
41	3397659	Block, Terminal
51	8066217	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	8066065	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16−18 x 3/4
59	8066184	Pulley, 60 Hz.
62	8066206	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
64	3404162	Clamp, Motor (W/Shield)
67	3405246	Seal, Door
68	697776	Screw, 10−32 x 5/8 (External Ground)

TOP AND CONSOLE PARTS

For Model: WED5310SQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: WED5310SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console
4	8271365	Cap, End (L.H.)
6	388326	Screw, Console
7	693995	Screw, Hex Head
8	8271359	Cap, End (R.H.)
9	3395683	Housing, Connector (Motor)
10	8557857	Screen, Lint
11	8536939	Clip, Spring
12	8533971	Screw, 8−18 x 5/16
13	688983	Screw, 8−18 x 5/8
14	8533951	Screw, Grounding
16	8557930	Top
18	94614	Terminal
21	8299779	Timer, 60 Hz.
23	3394427	Clip, Harness
30	357213	Nut, Push−In (2)
32	8299867	Harness, Wiring
33	3977456	Switch, Push−To−Start
34	8566061	Timer Knob Assembly
35	8566065	Knob, Control
36	3936144	Connector
37	8544895	Bracket, Control
38	W10028970	Panel, Control

BULKHEAD PARTS

For Model: WED5310SQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8−18 x 5/8
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	Thermostat, Internal−Bias
9	3977393	Thermal Cut−Off (Includes Illus. 15)
10	694089	Wheel, Blower (Includes Illus. 22)
11	8577230	Housing, Blower
12	8066155	Clip
13	343641	Screw, 10−16 x 1/2
14	8541818	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
17	8565582	Element, Heater
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
24	8066086	Drum Hole Plug
25	3390647	Screw, 8−18 x 1/2
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397590	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8−16
48	3403491	Bulkhead
62	692526	Ring, Bearing
63	97787	Screw, 11−16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: WED5310SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
		ACCESSORY PARTS
	279948	Kit, Dryer Repair
	8522199	Kit, Dryer Vent Testing
	3404351	Dry Rack
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)